



Art-Nr. Part No.		Ø innen Ø Inside cm	Höhe außen Outer Height cm	Ø Boden Ø Base cm	Preis €
2207/160	2,5 l	16	13	15	28,—
2207/200	4 l	20	15	19	39,—
2207/240	7 l	24	17	23	52,—
2207/280	10 l	28	19	27	67,—
2207/320	15 l	32	21	31	89,50
2207/360	22 l	36	23	35	115,—
2207/400	28 l	40	26	39	151,—
2207/450	44 l	45	29	40	210,—
2207/500	60 l	50	33	49	270,—

Deckel bitte separat bestellen (Art. 2261)

Please order lids separately (Part No. 2261)



Kochtopf, niedrig

Deep Casserole

Art-Nr. Part No.		Ø innen Ø Inside cm	Höhe außen Outer Height cm	Ø Boden Ø Base cm	Preis €
2209/160	1,5 l	16	8	14	23,85
2209/200	3,5 l	20	11	19	35,—
2209/240	5 l	24	12	23	46,—
2209/280	8 l	28	14	27	59,50
2209/320	12 l	32	17	31	82,—
2209/360	10 l	36	12	35	93,—
2209/400	15 l	40	14	39	122,—
2209/450	20 l	45	15	44	165,—
2209/500	38 l	50	20,5	45	220,—

Deckel bitte separat bestellen (Art. 2261)

Please order lids separately (Series 2261)



Bratentopf

flache Form

Casserole/Braising Pan

shallow

Art-Nr. Part No.		Ø innen Ø Inside cm	Höhe außen Outer Height cm	Ø Boden Ø Base cm	Preis €
2206/160	2,5 l	16	13	15	27,30
2206/180	3,25 l	18	13	17	31,—
2206/200	4 l	20	15	19	38,50
2206/240	7 l	24	17	23	49,—

Deckel bitte separat bestellen (Art. 2261)

Please order lids separately (Part No. 2261)



Stielkasserolle, hoch

mit Rohrgriff

Deep Sauce Pan

with hollow handle

Art-Nr. Part No.		Ø innen Ø Inside cm	Höhe außen Outer Height cm	Ø Boden Ø Base cm	Preis €
2208/160	1,5 l	16	10	15	24,10
2208/180	2,5 l	18	10	17	28,25
2208/200	3 l	20	11	19	33,50
2208/240	5 l	24	12	23	44,50

Deckel bitte separat bestellen (Art. 2261)

Please order lids separately (Series 2261)



Stielkasserolle, niedrig

Sautoirform, mit Rohrgriff

Shallow Sauté Pan

with hollow handle